

When using a trim, the additional foam gasket must be adhered behind the white bezel of the light fitting to maintain the seal against the ceiling.

1. Remove paper backing from foam gasket
2. Position sticky side facing the existing gasket on rear of the FIRELEDPCS bezel
3. Press gently to secure into position

